

Setting new ICC profile for Adobe Photoshop

Installation and the setting to the PC are necessary to use the new ICC profile.
Please carry out installation in the following procedures.

For Windows

Installation of ICC profile

- 1) Choose the new ICC profile that downloaded. Click the right button of the mouse and display the menu.
Choose [installation profile].
The new ICC profile is copied automatically in [Windows¥System32¥Spool¥Drivers¥Color].

Usage of the ICC profile

- 1) Display a print window.
Open the image to print on Adobe Photoshop. Choose [Print] in the [File] menu.
- 2) Select the printer.
Select [ASK-2500] and click the "Page Setting" button.
- 3) Set the printer property.
- 4) Set [Color Management].
Choose [Color Management] and set an option.
 - Color Handling: [Photoshop Manages Colors]
 - Printer Profile: [Choose the new profile]
※[Rendering intent] choose [Perceptual] or [Relative Colormetric] .
- 5) Set the print size and the print number of sheets. Starts printing that click the "Print" button.

For Macintosh

Installation of ICC profile

- 1) Copy new ICC profile in this folder.
Library/ColorSync/Profiles

Usage of the ICC profile

- 1) Display the print window.
Open the image to print on Adobe Photoshop. Choose [Print preview] in the [File] menu.
- 2) Set [Color Management].
Choose [Color Management] and set an option.
 - Color Handling: [Photoshop Manages Colors]
 - Printer Profile: [Choose the new profile]
※[Rendering intent] choose [Perceptual] or [Relative Colormetric] .
- 3) Click the "Print" button after confirmation of the setting.
- 4) Select the printer.
Select [ASK-2500] and click the "Page Setting" button.
- 5) Set the print size and the print number of sheets. Starts printing that click the "Print" button.