

See more, with certainty



The binoculars of the Fujinon KF series. Sharp images and robust construction to meet professional requirements

- ▶ Police
- ▶ Border guards
- ▶ Rescue services

Fujinon. To see more is to know more.

FUJINON

The binoculars of the KF series in detail

- ▶ Professional roof prism binoculars for rapid, simple and comfortable observation in almost any situation
- ▶ Thanks to the precise central focusing it is possible to easily bring details into sharp focus with just a small movement of the finger (except KF 7x28H)
- ▶ The nitrogen filling prevents the binoculars from fogging inside and also avoids the formation of condensation
- ▶ The rubber armouring that resists the most aggressive contaminants is easy to hold even in hot, cold or rainy conditions
- ▶ Handy, robust, long-lived: The binocular sits perfectly in your hands and is extremely resistant to impacts thanks to the high-quality aluminium housing
- ▶ High-quality technologies and phase-coated prisms provide an optical treat with bright and sharp images that reveal the smallest detail
- ▶ Multicoating protects the lenses against outside influences and makes it easier to clean them



Technical data	 KF 8x32W	 KF 10x32W	 KF 8x42H	 KF 10x42H	 KF 7x28H
Magnification	8x	10x	8x	10x	7x
Objective diameter (mm)	32	32	42	42	28
Eye relief (mm)	14.5	14.5	18	13	15
Field of view	7.5°	6.5°	7.5°	6°	7.3°
Field of view at 1,000 m (m)	131.1	113.5	131	105	128
Exit pupil (mm)	4.0	3.2	5.25	4.2	4
Twilight factor	16	17.8	27.6	17.6	14
Minimum focus (m)	2.5	2.5	2.5	2.5	5
Adjustment range for interpupillary distance (mm)	58–72	58–72	5–74	56–74	58–70
Dimensions WxHxD (mm)	131 x 139 x 53	131 x 139 x 53	137 x 147 x 55	137 x 143 x 55	113 x 121 x 39
Weight (g)	470	480	670	670	340

Specifications are subject to change without notice. 10/18

FUJIFILM

FUJIFILM Optical Devices Europe GmbH

Fujistraße 1, 47533 Kleve, Germany
 Tel.: +49 (0) 2821-7115-400, Fax: +49 (0) 2821-7115-200
www.fujifilm.eu/fujinon